

ABS**Cruise Control (CC)**

760-03-01	xxxx-x*xx-xx	Current	3	New	4
-----------	--------------	---------	---	-----	---

IPC**AEIS With Override (AEISWO) · ABS Configuration (ABSC) · ACC_Menu_Cfg (ACCMC) · Adaptive Cruise (AC)**

720-01-01	x*xx-xxxx-xx	Current	F(?)	New	F
-----------	--------------	---------	------	-----	---

Forward Collision Warning (FCW) · FFV (FFV) · Front Fog (FF)

720-01-02	xxxx-*x	Current	8	New	8
-----------	---------	---------	---	-----	---

Temperature Curve (TC) · TSR IOD (TSRIOD) · Upshift Indicator (UI) · Intelligent Speed Assistance (ISA)

720-03-01	x*xx-xxxx-xx	Current	1	New	1
-----------	--------------	---------	---	-----	---

Traffic Sign Recognition (TSR) · Trailer Sway (TS) · Tracking and Blocking System (TBS) · Trip Stats Pause (TSP)

720-03-02	xx*x-xxxx-xx	Current	0	New	0
-----------	--------------	---------	---	-----	---

Trailer Blind Spot (TBS) · Trailer Reverse Guidance (TRG) · SBW eShifter Type (SBWST) · Evasive Steering Assist (ESA)

720-09-01	*xxx-xxxx-xx	Current	3	New	3
-----------	--------------	---------	---	-----	---

SLIF (SLIF) · HUD_Cfg (HUDC) · FCW_AmberRTT_Cfg (FCWARTTC)

720-09-01	xxxx-xxxx-*x	Current	9	New	9
-----------	--------------	---------	---	-----	---

Adaptive Steering Comfort Menu (ASCM) · MFD (MFD) · Intelligent Adaptive Cruise Control (IACC) · Adaptive Headlamps Feature (AHF)

720-09-02	*xxx-xxxx	Current	0	New	2
-----------	-----------	---------	---	-----	---

Dim II Control Mirror (DIICM) · TSR NCAP Adaptations (TSRNCAPA) · HDC Control Function (HDCCF) · Traffic Jam Assist (TJA)

720-10-01	x*xx-xxxx-xx	Current	0	New	1
-----------	--------------	---------	---	-----	---

BCM**EngineFuelCapability (EFC) · CruiseControl (CC)**

726-16-01	xxxx-xx**~xx	Current	8C	New	90
-----------	--------------	---------	----	-----	----

IMPORTANT: Disconnect FORScan and turn the car completely off, then back on. Reconnect FORScan BUT do not use the saved profile. Let it rescan for all modules.

APIM**Display Speed Limit in HMI (DSLHMI)**

7D0-05-01	*xxx-xxxx-xx	Current	2	New	2
-----------	--------------	---------	---	-----	---

Electric Horizon (EH) · Electric Horizon Type (EHT)

7D0-05-01	xx*x-xxxx-xx	Current	8	New	8
-----------	--------------	---------	---	-----	---

AEIS Without Override (AEISWO) · AEIS with Override (AEISO) · ACC Menu (ACCM) · Adaptive Head Lamps Control Function (AHLCF)

7D0-09-01	*xxx-xxxx-xx	Current	6	New	6
-----------	--------------	---------	---	-----	---

Easy Entry/Exit (EEE) · Forward Collision Warning (FCW) · Fuel Operated Heater (FOH)

7D0-09-01	xxxx-*xxx-xx	Current	4	New	4
-----------	--------------	---------	---	-----	---

Remote Start – Rear Defrost (RSRD) · Remote Start – Steering Wheel (RSSW) · Side Detect (SD) · Intelligent Speed Assistance (ISA)

7D0-09-01	xxxx-xxxx-x*	Current	F	New	F
-----------	--------------	---------	---	-----	---

Evasive Steering Assist (ESA) · Lane Assist Haptic Intensity (LAHI) · Intelligent Adaptive Cruise Control (IACC) · Adaptive Headlamps Feature (AHF)

7D0-09-02	xxx*-xxxx-xx	Current	C	New	E
-----------	--------------	---------	---	-----	---

APIM (cont)

Traction Control/IVD/RSC (TCIVDRSC) · Adaptive Cruise (AC) · TSR NCAP Adaptations (TSRNCAPA)

7D0-09-02	xxxx-x*xx-xx	Current	7	New	7
-----------	--------------	---------	---	-----	---

Traffic Sign Recognition (TSR) · TPMS By Location (TPMSBL) · TPMS Placard Pressure Display (TPMSPPD) · Centerstack Settings (CS)

7D0-09-02	xxxx-xxxx-x*	Current	D	New	D
-----------	--------------	---------	---	-----	---

Speed Limit Menu (SLM) · Cruise Control Variant 2 (CCV) · Lane Centering (LC) · Smart Offering (SO)

7D0-09-04	xxxx-xxxx-*x	Current	A	New	E
-----------	--------------	---------	---	-----	---

Vehicle Locks (VL) · Curve Speed Control Menu (CSCM) · Predictive Speed Assist (PSA) · NFC Key (NFCK)

7D0-09-05	xxxx-xxxx-*x	Current	0	New	2
-----------	--------------	---------	---	-----	---

IPMA

ModuleFeatureCfg_DistAlert (MFCDA) · ModuleFeatureCfg_FcwHUD (MFCFHUD)

706-01-01	*xxx-xxxx-xx	Current	8	New	8
-----------	--------------	---------	---	-----	---

ModuleFeatureCfg_TSR (MFCTSR) · ModuleFeatureCfg_IACC (MFCIACC)

706-01-01	xx*x-xxxx-xx	Current	4	New	5
-----------	--------------	---------	---	-----	---

ModuleFeatureCfg_TJA (MFCTJA) · ModuleFeatureCfg_WWA (MFCWWA) · ModuleFeatureCfg_SBLM (MFCsBLM) · ModuleFeatureCfg_SRP (MFCsRP)

706-01-01	xxx*-xxxx-xx	Current	0	New	8
-----------	--------------	---------	---	-----	---

ModuleFeatureCfg_VideoOutput (MFCVO) · ModuleFeatureCfg_yrTAD (MFCTAD) · ModuleFeatureCfg_REMHarvest (MFCREMH) · ModuleFeatureCfg_REMLocalization (MFCREML)

706-01-01	xxxx-xxxx-x*	Current	2	New	2
-----------	--------------	---------	---	-----	---

IPMA (cont)

FeatureCfg_TSRMode (FCTSRM) · FeatureCfg_LKSMKey (FCLKSMK) · FeatureCfg_LKSSstrategy (FCLKSS) · FeatureCfg_DPAC_WrdRemoteCamera (FCDPACWRC)

706-02-01 **xx-xxxx-xx Current 6A New 6A

FeatureCfg_BLIS_RearRadar (FCBLISRR) · FeatureCfg_BLIS_FrontRadar (FCBLISFR) · FeatureCfg_CCM_CenterRadar (FCCCMCR)

706-02-02 xx*x-xxxx-xx Current 5 New 5

FeatureCfg_ACC_ExtendAutoResume (FCACCEAR) · FeatureCfg_ACC_OneButtonActivate (FCACCOBA) · FeatureCfg_REM_SignFusion (FCREMSF) · FeatureCfg_REM_PPFusion (FCREMPPF)

706-05-01 x*xx-xxxx-xx Current 4 New C

Unused_4 (U) · VehicleCfg_ACCType (VCACCT)

706-16-01 *xxx-xxxx-xx Current 1 New 1

VehicleCfg_APAlnterface (VCAPAI) · VehicleCfg_PCAType (VCPCAT)

706-16-01 xxx*-xxxx-xx Current B New B

PSCM

TJA (TJA)

730-02-02 xxxx-**xx-xx Current 00 New FF

LCA (LCA)

730-02-02 xxxx-xx**-xx Current 00 New FF

ESA (ESA)

730-02-03 **xx-xxxx-xx Current FF New FF

Okay, once again disconnect FORScan and turn the truck completely off, then back on. Reconnect FORScan BUT do not use the saved profile. Let it rescan for all modules. Once the scan is done, go to the DTC button on the left and **CLEAR ALL DTC**. This is very important. Cycle the engine after doing so.

Theoretically you will have a few errors on the screen such as front braking disabled or something like that. These are all related to the radar not being calibrated. You will use FORScan to calibrate.

- Go to the wrench icon on the left to get to the service menu.
- Select C-CM Calibration.
- You will now need to drive around in traffic while following some vehicles and let the truck calibrate.
- Once calibration has finished, the errors on the screen should disappear after a power cycling.

Additional Changes

IPMA

FeatureCfg_BA_DefaultMode (FCBADM) • FeatureCfg_IACCMMode (FCIACCM)
 706-02-02 xxxx-xxxx-x* Current 0 New 2

IPC

AltFuelEngInjectorType (AFEIT) • Stabilizer Bar Disconnect (SBD) • HMI: Oil Minder Menu (HMIOMM) • TJA-Metaphor (TJAM)

720-11-01 xx*x-xxxx-xx Current 2 New 3