
1
2
3
4
5
6
7
8
A
B
C
D
E
F
C2420 Speaker, LH A-pillar
C275 C299
C256 Passenger airbag
C2360 Collapsible steering column Module
C226A C226B Steering Column Control Module (SCCM)
C218A Clockspring
C2434 Steering column lock module
C2021 Speaker, RH A-pillar
C900
C919
14401
C245
G201
C260
C263
C918
G200 G202
C205 Headlamp switch
S229 S239
C3134
C213
C2607 Passenger Knee Airbag
C266 Footwell lamp RH
C390 Wireless Accessory Charging Module (WACM)
C2432 Driver knee airbag
C2422 Instrument Panel Cluster (IPC) Display Speaker
C2122 Remote Data Link Connector (DLC)
C2280B Body Control Module (BCM)
C2280A Body Control Module (BCM)
front of vehicle